

2008YM CBR1000RR8 HRC KIT FOB LIST

PART NUMBER	DESCRIPTION	QTY
06110-NLR-000	ENGINE POWER UP KIT	
1 14110-MFL-R10	CAM SHAFT COMP,IN	1
2 14210-MFL-R10	CAM SHAFT COMP,EXH	1
3 14321-NLR-A30	SPROCKET,CAM	2
4 14751-NLR-A30	SPG,IN VALVE OUTER	8
5 14752-NLR-A30	SPG,IN VALVE INNER	8
6 14761-NLR-A30	SPG,EX VALVE	8
7 90082-NL9-710	BOLT,FLANGE KNOCK,7X10.5	4
8 90488-425-000	WAHSER,	2

PART NUMBER	DESCRIPTION	QTY
06130-NLR-A30	ACG SET	
1 11321-NLR-A30	COVER,ACG	1
2 11322-NLR-A30	CLAMP,ACG CORD	1
3 11392-NLR-A30	GASKET,ACG COVER	1
4 31110-NLR-A30	ROTOR COMP	1
5 31120-NLR-A30	STATOR COMP	1
6 90003-NL9 -000	BOLT,FLANGE,10X35	1
7 90006-GHB -660	BOLT,FLANGE,NSHF,6X22	1
8 90006-GHB -680	BOLT,FLANGE,NSHF,6X28	8
9 90029-NLR-A30	BOLT, SEALING 14MM	1
10 94109-14000	WASHER, PLUG 14MM	1
11 95701-06016-00	BOLT,FLANGE,6X16	2
12 96600-06025-00	BOLT,SOCKET,6X25	4

PART NUMBER	DESCRIPTION	QTY
06210-NLR-A30	TRNSMISSON SET	
1 23211-MFL-R10	SHAFT,MAIN P-1	1
2 23421-MFL-R10	GEAR, C-1 P-1	1
3 23431-MFL-R10	GEAR, M-2 P-1	1
4 23441-MFL-R10	GEAR, C-2 P-1	1
5 23451-MFL-R10	GEAR, M-3 M-4 P-11	1
6 23461-MFL-R10	GEAR, C-3 P-1	1
7 23481-MFL-R10	GEAR, C-4 P-1	1
8 23491-MFL-R10	GEAR, M-5 P-1	1
9 23501-MFL-R10	GEAR, C-5 P-1	1
10 23511-MFL-R10	GEAR, M-6 P-1	1
11 23521-MFL-R10	GEAR, C-6 P-1	1
12 37700-NLR-A31	SPEED SENSOR ASSY	1

PART NUMBER	DESCRIPTION	QTY
06160-NLR-A30	AIR FUNNEL SET	
1 16514-NL9 -710	BOLT,5MM	6
2 17215-NLR-A30	FUNNEL,AIR#1	1
3 17216-NLR-A30	FUNNEL,AIR#2	1
4 17217-NLR-A30	FUNNEL,AIR#3	1
5 17218-NLR-A30	FUNNEL,AIR#4	1

PART NUMBER	DESCRIPTION	QTY
06180-NLR-A31	OIL COOLER SET	
1 15700-MFL-R11	COOLER COMP, OIL	1
2 19529-MFL-R10	HOSE C,OIL/C	1
3 19526-MFL-R10	HOSE A,OIL/C	1
4 90019-N1A -D00	BOLT,OIL COOLER	1

PART NUMBER	DESCRIPTION	QTY
06280-NLR-A30	DISK SET, CLUTCH	
1 22201-NL9-C30	DISK, CLUTCH FRICTION	1
2 22201-MEL-000	DISK, CLUTCH FRICTION	7
3 22201-NLR-A30	DISK, CLUTCH FRICTION	1
4 22321-MEL-000	PLATE, CLUTCH	7
5 22321-MN4-000	PLATE A, CLUTCH	1
6 22322-MEL-000	PLATE B, CLUTCH	1
7 22322-MN4-000	PLATE B, CLUTCH	1

PART NUMBER	DESCRIPTION	QTY
22326-MFL-R10	SPRING SEAT, JUDDER	1
22401-MFL-R10	SPRING, CLUTCH	1

PART NUMBER	DESCRIPTION	QTY
22870-NLR-000	CABLE COMP, CLUTCH	1

PART NUMBER	DESCRIPTION	QTY
16400-MFL-R11	THROTTLEBODY ASSY	1

PART NUMBER	DESCRIPTION	QTY
12251-NLR-A31	GASKET, CYLINDER HEAD 0.55	1
12252-NLR-A31	GASKET, CYLINDER HEAD 0.65	1
12253-NLR-A31	GASKET, CYLINDER HEAD 0.70	1
12254-NLR-A31	GASKET, CYLINDER HEAD 0.75	1

PART NUMBER	DESCRIPTION	QTY
12191-NLR-A31	GASKET, CYLINDER 0.20	1
12192-NLR-A31	GASKET, CYLINDER 0.30	1
12193-NLR-A31	GASKET, CYLINDER 0.15	1

PART NUMBER	DESCRIPTION	QTY
15220-NLR-000	VALVE ASSY, RELIEF(7K)	1

PART NUMBER	DESCRIPTION	QTY
31910-NLR-A31	SPARK PLUG (R0459A-10)	1

OPTIONAL MISSION GEARS

PART NUMBER	DESCRIPTION	QTY
23212-NLR-A30	SHAFT, MAIN, P-2	1
23213-NLR-A30	SHAFT, MAIN, P-3	1
23422-NLR-A30	GEAR, C-1, P-2	1
23423-NLR-A30	GEAR, C-1, P-3	1

23432-NLR-A30	GEAR, M-2,P-2	1
23433-NLR-A30	GEAR, M-2,P-3	1
23442-NLR-A30	GEAR, C-2,P-2	1
23443-NLR-A30	GEAR, C-2,P-3	1
23452-NLR-A30	GEAR, M-3 M-4,P-12	1
23453-NLR-A30	GEAR, M-3 M-4,P-21	1
23454-NLR-A30	GEAR, M-3 M-4,P-22	1
23455-NLR-A30	GEAR, M-3 M-4,P-31	1
23456-NLR-A30	GEAR, M-3 M-4,P-32	1
23462-NLR-A30	GEAR, C-3,P-2	1
23463-NLR-A30	GEAR, C-3,P-3	1
23482-NLR-A30	GEAR, C-4,P-2	1
23483-NLR-A30	GEAR, C-4,P-3	1
23492-NLR-A30	GEAR, M-5,P-2	1
23493-NLR-A30	GEAR, M-5,P-3	1
23494-NLR-A30	GEAR, M-5,P-4	1
23502-NLR-A30	GEAR, C-5,P-2	1
23503-NLR-A30	GEAR, C-5,P-3	1
23504-NLR-A30	GEAR, C-5,P-4	1
23512-NLR-A30	GEAR, M-6,P-2	1
23513-NLR-A30	GEAR, M-6,P-3	1
23514-NLR-A30	GEAR, M-6,P-4	1
23522-NLR-A30	GEAR, C-6,P-2	1
23523-NLR-A30	GEAR, C-6,P-3	1
23524-NLR-A30	GEAR, C-6,P-4	1

2008YM CBR1000RR8 HRC KIT FOB LIST

PART NUMBER		DESCRIPTION	QTY
06183-NLR-000		EXHAUST SET (SBK)	
1	18291-NLR-000	GASKET,EXH PIPE	4
2	18298-NLR-000	FLANGE,EXH	4
3	18292-NLR-000	COLLAR,EXH	4
4	18300-NLR-000	PIPE, ASSY, EXH	1
	18301-NLR-000	PIPE COMP,EXH(#1)	1
	18302-NLR-000	PIPE COMP,EXH(#2)	1
	18303-NLR-000	PIPE COMP,EXH(#3)	1
	18304-NLR-000	PIPE COMP,EXH(#4)	1
	18305-NLR-000	JOINT COMP	1
5	18336-NL9 -000	SPRING,EXH PIPE (AKRAPOVIC)	8
6	18336-NLR-A30	SPRING,EXH PIPE (SHORT)	6
7	18372-NLR-000	STAY, EXH PIPE	1
8	18375-NLR-000	STAY, EXH PIPE(20)	1
9	18380-NLR-010	MUFFLER COMP(SB)	1
10	95701-08020-00	BOLT, FLANGE 8 × 20	8
11	90201-GCC-C500	NUT, HEX. , 7MM	2
12	95701-08016-00	BOLT, FLANGE 8 × 16	1
13	95701-06010-00	BOLT, FLANGE 6 × 10	1
14	19051-KA3-830	RUBBER, RAD MT	1
15	90403-KA3-830	WASHER, RAD MT	1
16	19052-MAC-680	COLLAR, RAD. MT	1
17	95701-06030-00	BOLT, FLANGE 6 × 30	1
18	94050-06000	NUT, FLANGE, 6MM	1
19	18339-NL9-910	GREASE, ANTI SEIZING	1

PART NUMBER		DESCRIPTION	QTY
06183-NLR-A31		EXHAUST SET (AMA)	
1	18291-NLR-000	GASKET,EXH PIPE	4
2	18298-NLR-000	FLANGE,EXH	4
3	18292-NLR-000	COLLAR,EXH	4
4	18300-NLR-000	PIPE, ASSY, EXH	1
	18301-NLR-000	PIPE COMP,EXH(#1)	1
	18302-NLR-000	PIPE COMP,EXH(#2)	1
	18303-NLR-000	PIPE COMP,EXH(#3)	1
	18304-NLR-000	PIPE COMP,EXH(#4)	1
	18305-NLR-000	JOINT COMP	1
5	18336-NL9-000	SPRING,EXH PIPE (AKRAPOVIC)	8
6	18336-NLR-A30	SPRING,EXH PIPE (SHORT)	6
7	18372-NLR-000	STAY, EXH PIPE	1
8	18375-NLR-000	STAY, EXH PIPE(20)	1
9	18380-NLR-A31	MUFFLER COMP(JSB)	1
10	95701-08020-00	BOLT, FLANGE 8 × 20	8
11	90201-GCC-C50	NUT, HEX. , 7MM	2

12	95701-08016-00	BOLT, FLANGE 8 × 16	1
13	95701-06010-00	BOLT, FLANGE 6 × 10	1
14	19051-KA3-830	RUBBER, RAD MT	1
15	90403-KA3-830	WASHER, RAD MT	1
16	19052-MAC-680	COLLAR, RAD. MT	1
17	95701-06030-00	BOLT, FLANGE 6 × 30	1
18	94050-06000	NUT, FLANGE, 6MM	1
19	18339-NL9-910	GREASE, ANTI SEIZING	1

PART NUMBER	DESCRIPTION	QTY	
06321-NLR-000	HARNESS SET		
1	32100-MFL-R10	HARNESS WIRE	1
2	32170-NLR-A30	SUB CORD, SPEED SENSOR	1
3	32401-MFL-R10	CABLE START BAT	1
4	32405-MFL-R10	CABLE STARTER & EARTH	1
5	35160-MBW -Y02	SENSOR ASSY BANK ANGLE	1
6	35200-MFL-R10	SW ASSY,WINKER	1
7	35860-MBW -A10	SET START MAG	1
8	37100-MFL-R10	METER ASSY COMB	1
9	37700-GET-731	SENSOR ASSY,SPEED	1
10	38500-GC7-612	RELAY ASSY,START	2
11	38770-NLR-A30	UNIT ASSY PGM-FI/IGN	1
12	38771-NLR-A30	CD-ROM,PGM-FI/IGN	1
13	90620-SB2-003	BAND,WIRE HARN	1
14	90650-KV6-003	BAND,WIRE	1
15	90651-KV6-003	BAND,WIRE	2
16	91405-943-000	CLIP,CORD	1

PART NUMBER	DESCRIPTION	QTY	
06176-NLR -000	RUBBER SET,FUEL PUMP		
1	16711-NLR-000	SPACER,FUEL PUMP	1
2	17518-NLR-000	RUBBER,FUEL PUMP	1
3	17574-NLR-000	PACKING, SPACER	1
4	17575-NLR-000	PLATE,FUEL PUMP SETTING	1
5	90105-MM4-000	SCREW, PAN, 6 × 10	6

PART NUMBER	DESCRIPTION	QTY	
06502-NLR-010	SEAT RAIL SET		
1	31510-NLR-000	TRAY COMP, BATTERY	1
2	31517-NL9 -910	SPONGE,MT 3MM	1
3	35856-MBG -003	RUBBER SHOCK	1
4	50240-NLR-010	SEAT RAIL COMP	1
5	52430-NL9 -910	PLATE,RR CHSH ADJ	1
6	94050-06000	FLANGE NUT,6MM	2
7	96001-06012-00	BOLT,FLANGE,SH,6X12	3
8	96001-06014-00	BOLT,FLANGE,SH,6X14	1
9	96300-10020-00	BOLT,FLANGE,DR.10X20	2
10	35856-KBH -000	RUBBER,SHOCK	1

PART NUMBER	DESCRIPTION	QTY
-------------	-------------	-----

06405-NLR-000		DRIVE CHAIN ADJ SET	
1	40542-NLR-000	ADJ,R DRIVE CHAIN	1
2	40543-NLR-000	ADJ,L DRIVE CHAIN	1
3	40544-NLR-000	LID L DRIVE CHAIN ADJ	1
4	40545-NL9 -000	SPACER, ADJ. DRIVE CHAIN L	1
5	41405-HA7 -670	RING,STOPPER	1
6	42301-NL9 -000	AXLE,RR WHEEL	1
7	42302-NL6 -700	GUIDE,RR AXLE CNT	1
8	42304-NL9 -C40	COLLAR ,RR AXLE R	1
9	42314-NLR-000	COLLAR ,RR AXLE L SIDE	1
10	90308-NL9 -000	NUT,RR AXLE	1
11	90536-NL9 -000	WASH,RR AXLE	1
12	96001-06012-00	BOLT,FLANGE,SH,6X12	2
13	90106-NL9 -000	BOLT,HEX. 8 x 55	2
14	90309-357-000	NUT,HEX 8MM	4
15	90119-KC5-000	BOLT,CHAIN ADJUSTER	2

06552-NLR-000		BREATHER CASE SET (SBK)	
1	18315-GAG-750	RUBBER A,PROTR	2
2	18532-634-670	CLIP, AIR HOSE 21.5	1
3	19505-KS6-700	CLAMP A,WATER HOSE	5
4	31517-NL9-000	SPONGE,MT 5MM	1
5	55200-NLR-000	CASE COMP,BREATHER	1
6	55210-NLR-000	TUBE,BREATHER	1
7	55220-NLR-000	TUBE,BREATHER RETURN	1
8	84706-163-670	COLLAR,TAIL LIGHT MT	2
9	95005-80900-20	TUBE, 8.0X900	1
10	90525-030 -000	WASHER B, HANDLE HOLDER	2
11	96001-06022-00	BOLT,FLANGE,SH,6X22	2

PART NUMBER	DESCRIPTION	QTY
17910-NLRA-0001	CABLE COMP A,THROT	1
17920-NLRA-0001	CABLE COMP B,THROT	1

PART NUMBER	DESCRIPTION	QTY
18371-NLR-000	MUFFLER STAY for HRC seat rail set	1
18371-NLR-A20	MUFFLER STAY for stock seat rail	1

PART NUMBER	DESCRIPTION	QTY
19010-MFL-R11	RADIATOR COMP	1
19502-MFL-R10	PIPE, L RADIATOR	1

PART NUMBER	DESCRIPTION	QTY
38200-NLR-A30	SENSOR ASSY, SHIFT FORCE	1

PART NUMBER	DESCRIPTION	QTY
43110-NLR-000	BRACKET,RR CALIPER	1

PART NUMBER	DESCRIPTION	QTY
-------------	-------------	-----

45130-NLR-A30	SPACER,FR BRAKE DISK 0.2	2
---------------	--------------------------	---

PART NUMBER	DESCRIPTION	QTY
53700-NLR-003	DAMPER ASSY,STRG	1

PART NUMBER	DESCRIPTION	QTY
52400-MFL-R11	CUSHION ASSY, RR	1
52470-MFL-000	CONN ROD ASSY,CUSHION	1

PART NUMBER	DESCRIPTION	QTY
64501-NLR-000	STAY,UPPER COWL	1

PART NUMBER	DESCRIPTION	QTY
64503-NLR-000	STAY, CATCH TANK	1

PART NUMBER	DESCRIPTION	QTY
35400-NLR-A30	SW ASSY MODE	
52100-MFL-R10	SWINGARM ASSY, RR	
19526-NLR-000	HOSE A,OIL/C	
32401-MFL-R10	CABLE START BAT	
32405-MFL-R10	CABLE STARTER & EARTH	
44692-NLR-A20	STAY, VFW SENSOR	
44692-NLR-A30	STAY, VFW SENSOR	
52430-NLR-A20	STAY, RR CUSH ADJ	
52430-MFL-R10	STAY, RR CUSH ADJ	
53717-NLR-A00	STAY R,SHELTER	
53718-NLR-A00	STAY L,SHELTER	
35200-MFL-R10	SW ASSY, WINKER	
64503-NLR-A20	STAY, CATCH TANK	
37100-MFL-R10	METER ASSY COMB	
51497-NLR-A30	SPACER, FR FORK(BR)	
32100-MFL-R10	HARNESS WIRE	
52461-NLR-A20	ARM PLATE,CUSH(MEL)	
52461-NLR-A30	ARM PLATE,CUSH(P2)	
52461-NLR-A40	ARM PLATE,CUSH(P4)	
52470-NLR-A20	CONN ROD ASSY,CUSHION	
52470-NLR-A30	CONN ROD ASSY,CUSHION(P2)	
52470-NLR-A40	CONN ROD ASSY,CUSHION(P4)	
53707-NLR-A00	STAY R,STRG DAMPER	
53708-NLR-A00	STAY L,STRG DAMPER	
45120-MFL-R11	DISK, COMP R FR BRK	
45220-MFL-R11	DISK, COMP L FR BRK	
38770-MFL-R11	UNIT COMP PGM-FI/IGN	
51400-MFL-R11	FORK ASSY, R FRONT	
51500-MFL-R11	FORK ASSY, L FRONT	
51403-MFL-R11	COLLAR, SPRING	
51404-MFL-R11	COLLAR, B SPRING	